





SX22 / SX22W & SX26 / SX26W & SX30 / SX30W




FILLABLE SPEAKER STAND


Supplied Parts and Hardware




1. Remove Screws





2. Assemble Base





3. Install Feet




4a. Choose Feet (Soft Flooring)








4b. Choose Feet (Hard Flooring)





5. Manage Cables




6. Fill Stand (Optional)



7. Mount Top Plate




8. Mount Top Foam (Optional)



9. Level

9.1



9.2

